Sup. Ref.	MW5	Artwork Date:	24-06-22	Printing:	**Black**
LOTRONIC REF.	MICPRO-HF/ROADY-FL-MIC	Delivery Date:		Background:	WHITE PAPER
LOTRONIC CODE:	17-2062/17-2061	Page Dimensions (LxH):	**100 mm x 120 mm**	**MANUAL**	
LOTRONIC BRAND:	C.PERKINS				

C.Perkins

Rechargeable Wireless UHF Microphone

MIC-PRO-HF (with receiver)
Code: 17-2062
ROADY-FL-MIC (w/o receiver)
Code: 17-2061

COMPATIBLE WITH ROADY-FL

CE UK CA

Imported from China by **LOTRONIC S.A.**
Av. Z. Gramme 9 • B-1480 Saintes

Description

Wireless microphone for our ROADY-FL combo that will give clarity and full rich sound to your voice.

- Display with frequency and battery status
- LED indicator which lights up steadily or only to the sound of your voice
- Possibility to change frequency in case of interference
- Rechargeable via USB
- Supplied with USB charger lead

Battery life time	4-8h
Charging time	3-4h
Charging port	USB type C
Battery	3.7Vdc 1600mAh
Sensitivity	-50dB +/-3dB
Freq. range	100Hz – 10kHz
UHF range	10m
UHF frequency band	863-865MHz
Dimensions	211 x 47 x 47mm
Weight	0.256kg

Function Diagram

Mic core

Light ring : 2 operating modes
Steady on or flashing when somebody talks into the microphone

LED display: shows the operating frequency and state

Turn On/Off: Long press to tun on/off, short press to change the light mode

Pairing button: Press this button with a sharp object 10 seconds after power on. The mic will enter pairing state and the LED will flash. Turn on the speaker to pair the mic with the speaker. Short press this button to quit.

Short press again to change frequency.

Transmitting antenna: Do not cover the antenna during operation otherwise the transmission distance will be reduced.

USB-C connector to charge the built-in battery via the supplied USB lead

MIC-PRO-HF ONLY

Battery indicator
Power on/off
Microphone 2 connection indicator
Microphone 1 connection indicator
Battery indicator, red light on when charging, red light off when fully charged
Charging port, use DC 5V power supply

Download the multilanguage manual from our website

Téléchargez le manuel dans d'autres langues de notre site

Microphone UHF rechargeable

Ce mode d'emploi couvre les références:
MIC-PRO-HF (avec récepteur, utilisable sur toute enceinte équipée d'une entrée micro filaire)
Code: 17-2062
ROADY-FL-MIC (sans récepteur)
Code: 17-2061

COMPATIBLE AVEC ROADY-FL

Mehrsprachige Bedienungsanleitung von unserer Website herunterladen

Descargue el manual en otros idiomas desde nuestro sitio web

Description

Microphone sans fil pour notre combo ROADY-FL qui donnera clarté et richesse à votre voix.
- Affichage de la fréquence et de l'état de la batterie
- Indicateur LED qui s'allume en permanence ou seulement au son de votre voix
- Possibilité de changer de fréquence en cas d'interférences
- Rechargeable via USB
- Fourni avec un cordon de charge USB

Autonomie de la batterie	4-8h
Durée de charge	3-4h
Port de charge	USB type C
Batterie	3.7Vdc 1600mAh
Sensibilité	-50dB +/-3dB
Bande de fréquences	100Hz – 10kHz
Bande UHF	10m
Bande de fréq UHF	863-865MHz
Dimensions	211 x 47 x 47mm
Poids	0.256kg

Fonctions

Capsule du micro

Anneau lumineux : 2 modes de fonctionnement
Allumé en permanence ou clignotant lorsque quelqu'un parle dans le microphone

Affichage LED : indique la fréquence et l'état de fonctionnement

Marche/Arrêt: pression longue pour allumer/éteindre, pression courte pour changer le mode d'éclairage

Bouton d'appairage : Appuyez sur ce bouton pendant 10 sec. après la mise sous tension. Le micro entre en mode d'appairage et la LED clignote. Allumez le haut-parleur pour jumeler le micro avec le haut-parleur. Appuyez brièvement sur ce bouton pour quitter.
Appuyez brièvement pour changer de fréquence.

Antenne de transmission : Ne pas couvrir l'antenne pendant le fonctionnement, sinon la distance de transmission sera réduite.

Connecteur USB-C pour charger la batterie intégrée

Uniquement MIC-PRO-HF

Indicateur de batterie
Mise sous tension/hors tension
Indicateur de connexion du microphone 2
Indicateur de connexion du microphone 1
Indicateur de batterie, voyant rouge allumé en charge, voyant rouge éteint lorsque la batterie est chargée
Port de charge: utilisez le cordon USB fourni